kiddicare

Bouncy Hopper

"Fido" Model #108001-397
"Fire Patrol" Model #108001-398

IMPORTANT: RETAIN FOR FUTURE REFERENCE, READ CAREFULLY

SAFETY PRECAUTIONS

Read all instructions before assembly and use of the Bouncy Hoppers.
Keep instructions for future use.

⚠ WARNING ⚠

NOT SUITABLE FOR CHILDREN UNDER 3 YEARS OLD - SMALL PARTS

CAUTION

RECOMMEND AGE 3 YEARS +
MAXIMUM USER WEIGHT 50 KG
NEVER LEAVE CHILD UNATTENDED. ALWAYS KEEP CHILD IN VIEW WHILE USING PRODUCT
TO AVOID TIP OVER, USE PRODUCT ON A FLAT, LEVEL SURFACE
ENSURE CHILD IS USING THE HORN GRIPS WHEN USING RIDE ON FUNCTION
KEEP INSTRUCTIONS IN A SAFE PLACE FOR FUTURE REFERENCE

Adult assembly required. Inflate using supplied hand held pump and adapter only. Take care not to over inflate. Packaging materials are not toys. Remove all packaging including pump and adapter before giving this toy to a child.

Adult supervision is essential.
Use only under competent adult supervision. Young children in play are unaware of potential dangers and hazards.
Ensure play area is clear of any obstruction and sharp objects. Remove any sharp objects from children and play area, as these could cause injury to the use or damage the bouncy hopper.
Do not use as floating aid.
Do not expose to extreme temperatures. It is best to store an item inside and away from direct sunlight.

USAGE:
Before each use, check the area and clothing for sharp objects to prevent a puncture. Always keep a distance of 3 meters or more from others while playing. When playing with this product, stay away from stairs, pools and roads. Adult supervision required when playing with this product.

FOR SAFE PLAY:
1. ADULTS: Stand next to your child as they mount hopper with both feet flat on ground. Make sure child adjusts themselves until they are seated comfortably so they don't lose balance.
2. Hold firmly with both hands and look forward.
3. Gradually start out with small hopping forward movements to ensure balance and confidence.

Check what you have received...

You have received **1 bouncy hopper. 1 x pump. 1 x metal adapter**.
Please check the contents of the box If anything is missing, please contact Customer Service.
In Australia, contact **CNP Brands on 1300 667 137**, in New Zealand contact **Wainhouse Distribution on 0800 567 5000**.

Supplied loose in case:

1 x Bouncy Hopper

1 x Air Pump

INFLATION GUIDE

- Insert the pump into the valve on the underside of the bouncy hopper and inflate until firm. Over or under inflation can cause injury to the user and damage to the bouncy hopper.

- Once fully inflated remove the pump from the bouncy hopper. Store pump for future use.

NOTE:

- Inflation with a compressor may burst the bouncy hopper and is not recommended.

- PVC can be stretched over time, add more air as required.

HOW TO CARE FOR YOUR KIDDICARE BOUNCY HOPPER

Cleaning

This product has been designed and developed with safety, comfort and functionality in mind. Please take the time to read this manual carefully before using this product and keep it in a safe place for future reference.
To ensure the long-lasting use of your bouncy hopper, do not use abrasive cleaners. Always store product in a clean dry place. Wipe the bouncy hopper with a soft, clean cloth and mild soap.

Maintenance

Always check parts regularly for tightness of screws, nuts and other fasteners – tighten or replace if required.
To maintain the safety of your bouncy hopper, seek prompt repairs for bent, torn, worn or broken parts.
Use only those parts and accessories approved by CNP Brands. In Australia, contact CNP Brands on
1300 667 137, in New Zealand contact Wainhouse Distribution on 0800 567 5000.

kiddicare