

**Code EP34MWS - 34L Microwave Oven**



**6 AUTO COOKING MENU**

The Auto cooking menu, offers 6 pre set cooking functions including pizza, vegetable, beverage, dinner plate, potato and popcorn.

**SPEEDY COOKING (30 SECOND QUICK START)**

The quick start function enables you to start the unit at 100% power for 30 seconds, at the push of a button. Each press of the start button will increase the cooking time by an extra 30 seconds.

**FEATURES**

- 34L Capacity
- Digital touch control
- 1100W microwave power
- Auto cooking menus
- Child safety lock
- Grey painted cavity
- Stainless steel front panel finish
- Black outer housing

**TIMER**

Use to set microwave cooking time. Allows you to set up to 95 minutes.

**DEFROST BY TIME**

Use to set microwave defrost time. This function will allow you to set a maximum of up to 95 minutes.

**DEFROST BY WEIGHT**

Defrost food according to weight from 100g to 2kg.

**MULTI-STAGE COOKING**

This feature allows you to set multiple stages of cooking for example, the defrost function followed by microwave function.

**ELECTRICAL REQUIREMENTS**

This Microwave is fitted with a cord & 10amp plug.

**POWER CONSUMPTION:**

Rated input power (microwave): 1500w  
 Rated output power (microwave): 1100w  
 Rated input power (grill): 1100w  
 Rated Voltage: 220 - 240V

**WEIGHT:**

20.5kg (Gross) / 18.5kg (Net)

**OVEN CAPACITY:**

34 Litres

**CLEANING AND MAINTENANCE**

Simply clean the oven cavity with a slightly damp cloth

**PRODUCT DIMENSIONS**

Unit dimension with trim (W x H x D): 519x315x407mm

