



IMPORTANT CUSTOMER INFORMATION !

FISHER & PAYKEL

DW60 DETERGENT DISPENSER NOT OPENING OR DETERGENT BEING LEFT IN THE DISPENSER

Please be aware: If plates with a diameter or height greater than 230mm are loaded into the lower basket and are placed directly in front of the dispenser, the plates will prevent the door of the dispenser from opening fully and correctly dispensing the detergent or tablet.



Larger plates over 230mm can still be loaded in the rear of the basket or at the front to the right of the dispenser.