

40L countertop microwave oven, **1100**w, **6** sensor cook programs, quick start, favourite program, timer, child lock, white finish. RRP AUS \$299.00



Product Details

kitchen design

| FEATURES | | | |
|---|-------------|--|--|
| Counter top | Quick start | Class leading capacity | Child safety lock This feature prevents unwanted oven operation such as use by children |
| BENEFITS | | | |
| Seamless design integration The design perfectly integrates with the entire Westinghouse kitchen collection, allowing you to perfectly co-ordinate your | | Versatile cooking Multistage cooking from froz and time and weight defrost | zen to cooked, Quick Start cooking options |

Specifications

PRODUCT PROFILE

Domestic warranty details (yrs)

1

solo

327

553

453

Type of Microwave

PROGRAMS

| PROGRAM OPTIONS | |
|---------------------------------|-----|
| Number of Programmed functions | 6 |
| Auto cook programs | Yes |
| Auto cook from frozen programs | Yes |
| Auto weight defrosting programs | Yes |
| Auto weight programs | No |

DIMENSIONS

Total height (mm)

Total width (mm)

Total depth (mm)

PRODUCT

INTERNAL

Turntable diameter (mm) 345

CONTROLS

TIMER



WMF4102WA

CONTROLS

| Controls | touch |
|------------------------|-------|
| Child safety | Yes |
| Number of power levels | 10 |

| TI | N/ | F | P |
|----|-----|---|---|
| | 111 | | 1 |

| Type of timer | programmable timer |
|-----------------|--|
| Signals | end |
| Timer functions | acoustic signal,duration,stop,time of day |

EXTERIOR

| Туре | free standing (countertop) |
|------------------------|----------------------------|
| Fascia material/Colour | white |
| Trim | No |
| Outer wrap colour | white |

INTERIOR

| Interior finish | painted steel |
|------------------|-----------------|
| Interior Options | glass turntable |
| Grill | no grill |

DOOR

Door opening mechanism push button

Door opening

side opening

POWER

| Power Connection | 10 amp plug and cord |
|-----------------------|----------------------|
| Microwave power watts | 1100 |



Terms and Conditions

IMPORTANT

This is a guide of product dimensions only. For complete installation instructions, refer to the manual provided with product.

PRODUCT INFORMATION

The descriptors and illustrations in this publication apply to the specific products and models described as at the date of issue. Under our policy of continuous productdevelopment, product specifications may change without notice. Prospective purchasers should therefore check with their retailer to ensure this publication correctly describes theproducts that are being offered for sale. All information supplied is to be used for general reference purposes only and is on the understanding that Electrolux Home Products PtyLtd (Australia) and Electrolux (NZ) Ltd (New Zealand) will not be liable for any loss, liability or damage of whatever kind arising as a result of reliance on such information. Colours ofproducts illustrated are as close as printing limitations allow. Electrolux will at all times comply with its obligations pursuant to law including Trade Practices (Australian Consumer Law) Act and Regulations.

WARRANTY

This warranty only applies to Appliances purchased and used in Australia or New Zealand and used in normal domestic applications and is in addition to (and does not exclude, restrict, or modify in any way) any non-excludable statutory warranties in Australia or New Zealand. All warranties are subject to the conditions set out in the warranty card accompanying the product when purchased.

ELECTROLUX HOME PRODUCTS AUSTRALIA

telephone: 1300 363 640 fax: 1800 350 067 email: customercare@electrolux.com.au web: www.electrolux.com.au

ELECTROLUX HOME PRODUCTS NEW ZEALAND telephone: 09 573 2230 fax: 09 573 2221 email: customercare@electrolux.co.nz web: www.electrolux.co.nz