



GLIDERMATIC GTS

1. Remove the light cover from the motor
2. Locate the remote programming button on the motor's circuit board (Please refer to pictures)
3. Press the program button on the motor once and immediately release this button. A red light will illuminate (If the red light does not illuminate beside the button you have just pushed then this is the wrong button)
4. In less than 5 seconds, push and hold button A or button 1 on the new remote
5. The red light will go out and the remote is coded



GLIDEROL GRD

1. Remove the cover from the motor wall unit
2. Located the remote programming button on the motor's circuit board (Please refer to pictures)
3. Press the program button on the motor once and immediately release this button. A red light will illuminate (If the red light does not illuminate beside the button you have just pushed then this is the wrong button)
4. In less than 5 seconds, push and hold button A or button 1 on the new remote
5. The red light will go out and the remote is coded



Please Note: If you have more than one motor, you will use button A or button 1 for all motors and the motor will determine which button on the remote will operate the door.

www.remotepro.com.au

WARNING

To prevent possible **SERIOUS INJURY** or **DEATH**:
- NEVER allow small children near batteries.
- If battery is swallowed, immediately notify a doctor.

To reduce risk of fire, explosion or chemical burn:
- Replace **ONLY** with the same size and type battery

- **DO NOT** recharge, disassemble, heat above 100° C or incinerate

