

What's in the box?

(1) Projector (1) Power adapter (3) Image wheels


Getting started

1. PLUG IN THE PROJECTOR

Plug the right-angle end of the power adapter into the **DC IN** jack on the bottom of the projector.

Run the cable through the cable trough on the bottom of the projector. Then place the projector on a flat surface.

Plug the other end of the power adapter into a working outlet or surge protector.



2. LOAD AN IMAGE WHEEL

On the back of the projector, slide the image wheel door into the **FOR DISC ACCESS** position.


Take out the wheel drawer above the image wheel door.

Please an image wheel on the wheel drawer. Make sure the **UP** label is facing up.

Put the wheel drawer back into the image wheel door.

Slide the image wheel door up, into the **FOR PROJECTION** position.


IMPORTANT: The projector will not illuminate unless the image wheel door is in the up (**FOR PROJECTION**) position.



3. TURN ON THE PROJECTOR

To turn the projector on: Press the **PROJECTOR** button on the front of the projector.


To adjust brightness of the projector (or turn it off): Press the **PROJECTOR** button repeatedly to cycle through the settings (high, medium, low, and off).



4. ADJUST THE PROJECTOR POSITION

Make sure the image wheel door on the back of the projector is in the **FOR PROJECTION** position (pushed up).

Pull the projector lever below the image wheel door to adjust the projector position so that it points where you want.



Everyday use


PLAYING SOUNDS

The Project Nursery Sight + Sound Projector offers a variety of soothing lullabies and nature sounds, as well as white noise, to calm baby.

To cycle through these sounds: Press the **SOUND** button on the front of the projector. Each press goes to a different selection.

To adjust the volume: Press the **VOLUME -** or **+** button.


To turn sounds off: Press the **SOUND OFF** button on the top of the projector



PAIRING WITH YOUR PHONE (BLUETOOTH)

The Project Nursery Sight & Sound Projector can also play music from your smartphone or other Bluetooth device. Here's how to set it up.

Press and hold the **BLUETOOTH** button on the front of the projector until the indicator light next to this button starts blinking.



Enable Bluetooth on your smartphone or other device (if it isn't already enabled).

Choose **"Sight+Sound"** from the list of pairing options on your smartphone. (If it's not in the list, choose **"Scan"** from your phone's Bluetooth menu.)

The speaker gives an audio signal when it's finished pairing and connecting to your smartphone. The indicator turns solid blue.

Note: The process of enabling Bluetooth and connecting varies from device to device. See your device's owners manual for more information and specific instructions.

Bluetooth Wireless Connection Tips

- Make sure the Bluetooth capability of your device is turned on.
- The Bluetooth wireless connection works up to a range of roughly 33 feet (10 meters). This range may vary, however, based on other factors, such as room layout, wall material, obstacles, your device's Bluetooth performance, etc. If you're having problems connecting to this speaker, move closer to it.
- If your device asks you for a password to connect, use "0000".


USING THE TIMER

The timer shuts the projector and sound off automatically after a set amount of time.

To set the timer: Press the **TIMER** button on the front of the projector.

The **TIMER** indicator on the top front of the projector shows the amount of time on the timer: **15**, **30**, or **60** minutes.

Press **TIMER** to cycle through these options or turn the timer off.




USING THE LIGHT

The front of the Sight & Sound Projector offers soft area illumination in three levels of brightness, to complement the projector lighting.

To turn the light on: Press the **LIGHT** button on the front of the projector.

To adjust or turn off the light: Press the **LIGHT** button repeatedly to cycle through the settings (high, medium, low, and off).



project nursery® Bluetooth®

SIGHT & SOUND PROJECTOR

Quick Start Guide

Questions?

Just call 1-844-393-7338 or visit ProjectNursery.com

©2016 Vox Accessories Corp.
3502 Woodview Trace, Suite 220
Indianapolis, IN 46268

PNP100 QSG 00