

ZURI
CHANGE TOP
MODEL # 095611

IMPORTANT: RETAIN FOR FUTURE REFERENCE, READ CAREFULLY.

SAFETY PRECAUTIONS

Read all instructions before use of the change top. Keep instructions for future use.

⚠ WARNING ⚠

WARNING: DO NOT LEAVE THE CHILD UNATTENDED.

BEFORE USE OF THE CHANGE TOP, READ AND UNDERSTAND THE INSTRUCTIONS.

ALL ASSEMBLY FITTINGS SHALL ALWAYS BE CORRECTLY TIGHTENED AND CHECKED REGULARLY.

BE AWARE OF THE RISK OF OPEN FIRES AND OTHER SOURCES OF STRONG HEAT, SUCH AS ELECTRIC BAR FIRES, GAS FIRES ETC.

SUITABLE FOR CHILDREN UP TO 11 KGS AND CAN BE USED FROM BIRTH - 12 MONTHS OF AGE.

SUITABLE FOR COORDINATION WITH A CHANGE PAD MEASURING 750MM (L) X 500MM (W) X 100 (H).

PLACE CHANGE PAD DIRECTLY ONTO THE CHANGE TOP.

FALL HAZARD - TO PREVENT DEATH OR SERIOUS INJURY, ALWAYS KEEP CHILD WITHIN ARM'S REACH.

BEFORE PLACING YOUR CHILD ON THE CHANGE TOP, ENSURE THAT IT IS SECURELY ATTACHED TO THE FURNITURE.

ONLY USE THIS CHANGE TOP ON A LEVEL, STABLE AND STRUCTURALLY SOUND FURNITURE WITH A MINIMUM SURFACE DIMENSION OF 940MM X 490MM.

DO NOT USE CHANGE TOP, ADD ON CHANGING UNIT, OR CHANGE PAD IF IT DAMAGED OR BROKEN.


Check what you have received...

You have received 1 box. Please check the contents of the box against the list below. If anything is missing, please contact Customer Service. In Australia, contact CNP Brands on 1300 667 137, in New Zealand contact Wainhouse Distribution on 0800 567 5000.

Supplied loose in box:



Zuri Change Top
#095611
(Pre-assembled)



Attachment to Coordinating Item

- Metal Bracket x 2
- 14mm Screw x 8

RECOMMENDED ZURI CONFIGURATIONS



Zuri Drawer Chest
095610

+



Zuri Change Top
095611


+



Universal Change Pad
115153-003

=





ZURI
CHANGE TOP
MODEL # 095611

IMPORTANT: RETAIN FOR FUTURE REFERENCE, READ CAREFULLY.

IMPORTANT CONFIGURATION NOTE:

Before using the Zuri Change Top on top of the Zuri Drawer Chest, make sure to always attach it to the coordinating product using the attachments provided in the box. Always align the back of both items, with the change top screws facing the wall and always attach anti-tip furniture strap for added safety.

ATTACHING CHANGE TOP TO COORDINATING ITEM

A minimum of two metal brackets are used to attach the change top to the coordinating item using four screws per bracket.



- 1
- 1a. 2 pilot holes on each end of the coordinating product are already pre-drilled.
 - 1b. Place the Change Top onto the Drawer Chest.

Ensure the pre-drilled attachment holes of the Change Top are facing toward the back of the Drawer Chest.



- 2
- 2a. Align 1 x Metal Bracket with the predrilled attachment holes on the Change Top and the Drawer Chest.
 - 2b. Secure the Metal Bracket via 4 x 14mm attachment screws.
 - 2c. Repeat steps 2a. and 2b. for the remaining side.
 - 2d. Ensure both Metal Brackets are attached correctly and secure before use of the Change Top.

ADDITIONAL FURNITURE RANGE



Zuri Drawer Chest
#095610

For more information regarding our full range of coordinating furniture, please visit the CNP Brands website at www.cnpbrands.com.au and click the bebe care brand link, or contact our Sales Department on **1300 667 137** to make your enquiry.

HOW TO CARE FOR YOUR BEBE CARE FURNITURE

Maintenance

Always check parts regularly for tightness of screws, nuts and other fasteners – tighten or replace if required. To maintain the safety of your change top, seek prompt repairs for bent, torn, worn or broken parts. Use only those parts and accessories approved by CNP Brands.

Distributed in Australia by CNP Brands
82 Maribyrnong Street,
Footscray, VIC, 3011
Customer Service 1300 667 137

W: www.cnpbrands.com.au
E: info@cnpbrands.com.au
F: www.facebook.com/CNPBrands
I: @cnp_baby

Distributed in New Zealand by Wainhouse Distribution
2-6 Argyle St, Morningside,
PO Box 41-014,
St Lukes, Auckland, New Zealand
Customer Service: 0800 567 5000

E: helpline@wainhousedist.co.nz

