

DRAWER CHEST MODEL # 095610



IMPORTANT: RETAIN FOR FUTURE REFERENCE, READ CAREFULLY

SAFETY PRECAUTIONS



Read all instructions before assembly and use of the drawer chest. Keep instructions for future use.

A WARNING **A**

BEFORE USE OF THE DRAWER CHEST, READ AND UNDERSTAND THE INSTRUCTIONS.

ALWAYS USE ANTI-TIP STRAP THAT IS SUPPLIED WITH THIS PRODUCT TO PREVENT INJURY TO YOUR CHILD. THIS FURNITURE ITEM CANTIP WHEN THE ANTI-TIP STRAP IS NOT USED, ESPECIALLY WHEN PLACED ON CARPET, UNEVEN OR SLOPING FLOORING, OR WHEN SUBJECT TO EXTREME USE.

REMEMBER TO INSPECT YOUR CHEST OF DRAWERS REGULARLY FOR WEAR OR ACCIDENTAL DAMAGE, AND FOR THE SECURITY OF COMPONENTS.

KEEP INSTRUCTIONS IN A SAFE PLACE FOR FUTURE REFERENCE.




Congratulations on your purchase of the Zuri Drawer Chest.

This product has been designed and developed with safety, comfort and functionality in mind. Please take the time to read this manual carefully before using this product and keep it in a safe place for future reference.

Contents

Assembly contents list
Assembly / Operating instructions
How to care for your **Zuri Drawer Chest**



Due to variations in the style and design of our products, the photographs and illustrations shown in this instruction manual are generic, therefore product fabrics, colour and design may vary from images shown. CNP Brands reserves the right to alter product specifications without notice as a result of our ongoing policy of product improvement.



Check what you have received...

You have received 1 box. Please check the contents of the box against the list below. If anything is missing, please contact Customer Service.

In Australia, contact CNP Brands on 1300 667 137, in New Zealand contact Wainhouse Distribution on 0800 567 5000.

Supplied loose in box (Unit Components):

Zuri Drawer Chest



x 1 Foot Board



x 2

Anti-Tip Wall Strap Kit

- Wall Strap x 2
- 58mm Screw x 2
- 38 mm Screw x 4
- 16 mm Screw x 6
- Washer x 2



x 1 27mm Screws



x 6

Recommended Zuri Configurations:



Zuri Drawer Chest # 095610



Zuri Change Top # 095611



Universal Change Pad # 115153-003



Important Configuration Note:

Before using the Zuri Drawer Chest with the Zuri Change Top, make sure to always attach it to the coordinating product using the attachments provided in the box. Always align the back of both items, with the screws facing the wall and attach anti-tip furniture strap for added safety.

ASSEMBLY CONTENTS / ASSEMBLY / OPERATING INSTRUCTIONS



- a. As small parts are involved in assembly, children should be kept clear of the assembly area.
- b. Dispose of all packaging material immediately after the change centre is assembled.
- c. Identify all parts and components.
- d. Clear an area on the floor for assembly and place a sheet on the floor to ensure the change centre is not scratched during assembly.

To assemble Drawer Chest Foot Boards...



- Carefully lay the Drawer Chest down on its back.
- Insert 1 x Foot Board into the designated space on the underside of the Drawer Chest.
- 1c. Attach one Foot Board via 3 x 27mm Screws. Tighten until firm.
- 1d. Repeat for remaining Foot Board.







2a. Carefully lift and stand the Drawer Chest upright.



PLEASE NOTE: Two people are required to lift the Drawer Chest during assembly.


ANTI-TIP FURNITURE STRAP INSTALLATION




A minimum of two straps are used for each furniture piece using three screws per bracket. Brackets <u>must</u> be fixed to wall studs.




- 1a. Locate and mark timber wall studs behind furniture and corresponding position on the furniture surface.
- 1b. Position wall strap plates (screw holes facing down) on the wall stud about 150 mm below furniture top, then mark and drill pilot holes into wall surface, ensuring adequate contact with the timber wall studs.
- 1c. Attach wall strap plates to wall studs using 2 x 38mm screws and 1 x 58mm screw with washer.







- 2a. 3 pilot holes on each end of the product are already pre-drilled.
- 2b. Screw wall strap plates into solid timber area of furniture using three 16 mm screws.
- 2c. Slide furniture back into position and pull the wall bracket straps <u>until tight</u>.



HOW TO CARE FOR YOUR BEBE CARE COT



Cleaning

This product has been designed and developed with safety, comfort and functionality in mind. Please take the time to read this manual carefully before using this product and keep it in a safe place for future reference.

To ensure the long-lasting use of your drawer chest, wipe down with a damp cloth and use a mild soap solution if necessary. Do not use abrasive cleaners. Always store product in a clean dry place.

Maintenance

Always check parts regularly for tightness of screws, nuts and other fasteners – tighten or replace if required. To maintain the safety of your cot, seek prompt repairs for bent, torn, worn or broken parts. Use only those parts and accessories approved by **CNP Brands.**

If you have any difficulties in assembling the cot, please contact our Service Department.

In Australia, contact CNP Brands on 1300 667 137, in New Zealand contact Wainhouse Distribution on 0800 567 5000.







Distributed in Australia by CNP Brands 82 Maribyrnong Street, Footscray, VIC, 3011 Customer Service 1300 667 137

W: www.cnpbrands.com.au E: info@cnpbrands.com.au F: www.facebook.com/CNPBrands I: @cnp_baby Distributed in New Zealand by Wainhouse Distribution 2-6 Argyle St, Morningside, PO Box 41-014, St Lukes, Auckland, New Zealand Customer Service: 0800 567 5000

E: helpline@wainhousedist.co.nz





